SP100
Portable speaker
User Manual

Getting started:
Remove speaker from packaging

Charging:

Fully charge the Portable speaker before use.
Connect the speaker to the PC via the provided USB cable.

The LED at the base will turn red,
indicating that it is on charging mode.
The LED will turn off when fully charged.

Listening to Music:

1 Unwind the connector cable around the portable speaker base.

2 Plug in the connector to the Music source, e.g. PCs/Laptops, MP3 players or radios.



Listening to Music:



3 Turn on the Portable speaker ;
LED at the base will become green.

4 Start playing the selected Music.

Volume Adjustment :
SP100 comes with 2 levels of volume.



Volume level 1
Button at the middle
(Default when turn on)



Volume level 2
Button all the way towards “Right”